



Standard 4x3 (SD) (1.33) T.V setup. This is the correct framing for Reg 8mm, Super 8mm, 16mm film. It will cause side cropping for Super 16mm. Max 8 and Max 16 setups. This is a Standard Definition Choice.



Overscan (SD) allows you to see the full film image raw, without framing within the 4x3 ratio, including the top and bottom of the frames. It allows you to do the framing yourself.



16x9 (HD) allows the frame for wide screen formats and high definition. This is the correct framing for Super 16mm, Max 8, and Max 16 set up. It will cause cropping for Regular 8mm, and 16mm on the top and bottom of the frame.



4x3 Pilar Box (HD) This is the correct framing for Regular 8mm, Super 8mm, and 16mm film. Standard 1.33 film scanned to high definition will have black bars on both sides of the frame to fill the screen.



Overscan (HD) allows you to see the full film image raw, without framing within the 16x9 ratio, including the top and bottom of the frames. It allows you to do the framing yourself.